

SIGNAL PROCESSING
FOR DATASCIENCE
**EPILEPSY
PREDICTION**

TUH EEG SEIZURE CORPUS DATASET

Presented by:

Messaadi Ouday & Cherni Oussema



PLAN

1. Statistical Analysis

2. Data Visualization

3. Data Preprocessing


4. CNN Model

5. Results

REFERENCES


Reference	Method	Relevance to Our Work
Deep learning based automatic seizure prediction with EEG time-frequency representation X. Dong et al., 2024 ScienceDirect	<ul style="list-style-type: none">Multi-channel EEG from clinical databasesStockwell Transform → 2D time-frequency imagesMulti-Channel Vision Transformer (MViT)Pre-ictal vs inter-ictal prediction (~97% accuracy)	Very similar pipeline: EEG → time-frequency images (like your spectrograms) → CNN/vision model. Modern example of time-frequency + deep learning for seizure prediction.
EEG-based seizure prediction via Transformer guided CNN (TGCNN) C. Li et al., 2022 ScienceDirect	<ul style="list-style-type: none">STFT for EEG spectrogramsHybrid architecture: CNN (local features) + Transformer (long-term dependencies)Tested on CHB-MIT & Kaggle (~91.5% sensitivity, low false alarms)	Same approach: EEG spectrograms + CNN. Adds Transformer layer for global context. Excellent reference if you want to improve your CNN with attention mechanisms.
Semi-dilated convolutional neural networks for epileptic seizure prediction R. Hussein et al., 2021 ScienceDirect	<ul style="list-style-type: none">EEG → scalograms (wavelet-based time-frequency)2D CNN with semi-dilated convolutionsAdapted for elongated images (more temporal than frequency resolution)Pre-ictal vs normal prediction	EEG → time-frequency image → CNN. Shows how to adapt CNN architecture to spectrogram shape (filter sizes, dilation). Good inspiration for CNN design choices.
Convolutional neural networks for seizure prediction using intracranial and scalp EEG T. Truong et al., 2018 ScienceDirect	<ul style="list-style-type: none">Intracranial + scalp EEG (CHB-MIT + other datasets)CNN for pre-ictal vs inter-ictal predictionSliding temporal windowsPatient-specific vs generic models comparison	Same goal: seizure prediction with CNN. Discusses inter-patient generalization, which is crucial when working with large datasets like TUH TUSZ.

STATISTICAL ANALYSIS OVER THE TUH DATASET




STATISTICAL ANALYSIS OVER THE TUH DATASET



Seizure Duration Distribution
($\mu=206.8\text{s}$, median=35.9s)



Recording Duration Distribution
($\mu=707.9\text{s}$)



STATISTICAL ANALYSIS OVER THE TUH DATASET



STATISTICAL ANALYSIS OVER THE TUH DATASET


DATASET OVERVIEW	
Total Files Scanned	22,093
Valid EDF Files	7,364
Valid CSV Files	7,365
Valid CSV_BI Files	7,364
Invalid Files	0
PATIENT & SESSION INFO	
Unique Patients	675
Unique Sessions	221
Avg Recordings/Patient	10.91
Avg Sessions/Patient	2.43
DATA SPLITS	
Train Recordings	4,667
Eval Recordings	865
Dev Recordings	1,832
SEIZURE INFORMATION	
Total Seizure Events	9,943
Unique Seizure Types	8
Avg Seizure Duration	241.80s
Median Seizure Duration	59.98s
RECORDING DETAILS	
Avg Recording Duration	720.4s
Most Common Sampling Rate	256 Hz
Avg Channels/Recording	30.5
Unique Channel Names	99

DATA VISUALISATION USING MNE OVER THE SAME PATIENT DURING SEIZURE VS NON-SEIZURE RECORDING




EEG SIGNAL EXAMPLES: NON-SEIZURE VS SEIZURE


non-seizure




seizure



non-seizure



seizure




Evoked Responses (Trial-Averaged)

EEG (22 channels)

$N_{ave}=74$

non-seizure




Evoked Responses (Trial-Averaged)


EEG (22 channels)

$N_{ave}=230$


seizure



non-seizure topographic maps over the whole recording



seizure topographic maps over the whole recording




DATA PREPROCESSING PIPELINE


1 Filtering


2 Selection


3 Transformation


4 Construction
















spectrogram of an entire recording per channel




window (4s) spectrogram (grayscale)




sequence FOR VISUALIZATION PURPOSE


for the sake of visualization we applied PCA over the 26~29 channels of each window to end up with 3 channels to mimic RGB and we obtained the following image of our sequence



walkthroughs in Our CNN Model



ARCHITECTURE




RESULTS



Input EEG windows


10 windows \times
channels \times time–frequency



Windows
 \times channels

3D Conv blocks


Conv3D + ReLU
+ MaxPool




Feature extraction(3D CNN)

Fully-connected classifier

Global average
pooling over
(windows, frequency, time)



Global
average
pooling
over
(windows,
frequency,
time)



Fully-connected
classifier

displaying some statistics about our final dataset

```
prepared\all\train_sequences_index_balanced.csv
CSV utilisé : prepared\all\train_sequences_index_balanced.csv
      path  label  patient  session \
0  all/sequences/aaaaarjc_s007_t002_seq0083.npy    0  aaaaarjc  s007_2015
1  all/sequences/aaaaaqnr_s001_t000_seq0080.npy    0  aaaaqnr   s001_2014
2  all/sequences/aaaaaqtw_s002_t011_seq0037.npy    1  aaaaqtw   s002_2014
3  all/sequences/aaaaanme_s010_t010_seq0105.npy    0  aaaaanme  s010_2014
4  all/sequences/aaaaaqvx_s002_t001_seq0199.npy    0  aaaaqvx   s002_2015

      recording  last_win_center_s
0  aaaaarjc_s007_t002           186.0
1  aaaaqnr_s001_t000           180.0
2  aaaaqtw_s002_t011           156.0
3  aaaaanme_s010_t010           572.0
4  aaaaqvx_s002_t001          2658.0

Taille CSV : 9546
label
0    4773
1    4773
Name: count, dtype: int64
```

slicing data into : train , eavl , test

```
Taille train : 4787
Taille val   : 2274
Taille test  : 2485

Distribution des labels (train)
label
0    2658
1    2129
Name: count, dtype: int64

Distribution des labels (val)
label
1    1156
0    1118
Name: count, dtype: int64

Distribution des labels (test)
label
1    1488
0    997
Name: count, dtype: int64
```

applied grid search over 8 different configs to find the best hyperparameters

```
Epoch 4/5 - Train loss: 0.2195, acc: 0.916 | Val loss: 3.1655, acc: 0.478
Epoch 5/5 - Train loss: 0.1665, acc: 0.936 | Val loss: 1.9949, acc: 0.487

===== Config 6/8 =====
{'base_filters': 32, 'dropout': 0.3, 'lr': 0.0003}
Epoch 1/5 - Train loss: 0.5268, acc: 0.725 | Val loss: 1.4596, acc: 0.481
Epoch 2/5 - Train loss: 0.3008, acc: 0.874 | Val loss: 1.5081, acc: 0.515
Epoch 3/5 - Train loss: 0.1846, acc: 0.930 | Val loss: 1.9154, acc: 0.488
Epoch 4/5 - Train loss: 0.1489, acc: 0.945 | Val loss: 4.1871, acc: 0.493
Epoch 5/5 - Train loss: 0.1124, acc: 0.959 | Val loss: 2.6590, acc: 0.493

===== Config 7/8 =====
{'base_filters': 32, 'dropout': 0.5, 'lr': 0.001}
Epoch 1/5 - Train loss: 0.5725, acc: 0.688 | Val loss: 0.9749, acc: 0.455
Epoch 2/5 - Train loss: 0.3827, acc: 0.830 | Val loss: 2.2206, acc: 0.475
Epoch 3/5 - Train loss: 0.2774, acc: 0.884 | Val loss: 1.3930, acc: 0.469
Epoch 4/5 - Train loss: 0.2104, acc: 0.915 | Val loss: 1.4664, acc: 0.469
Epoch 5/5 - Train loss: 0.1715, acc: 0.933 | Val loss: 1.8539, acc: 0.493

===== Config 8/8 =====
{'base_filters': 32, 'dropout': 0.5, 'lr': 0.0003}
Epoch 1/5 - Train loss: 0.5320, acc: 0.722 | Val loss: 1.6043, acc: 0.500
Epoch 2/5 - Train loss: 0.3233, acc: 0.867 | Val loss: 1.2976, acc: 0.530
Epoch 3/5 - Train loss: 0.2183, acc: 0.914 | Val loss: 1.7081, acc: 0.505
Epoch 4/5 - Train loss: 0.1654, acc: 0.938 | Val loss: 2.4702, acc: 0.476
Epoch 5/5 - Train loss: 0.1318, acc: 0.952 | Val loss: 3.1573, acc: 0.505

===== Meilleure config trouvée =====
{'base_filters': 16, 'dropout': 0.3, 'lr': 0.0003}
Best val acc : 0.5224274406332454
```

Train

```
Epoch 1/20 - Train loss: 0.5473, acc: 0.700 | Val loss: 1.1719, acc: 0.504
-> Nouveau meilleur modèle sauvegardé.
Epoch 2/20 - Train loss: 0.3312, acc: 0.862 | Val loss: 1.3441, acc: 0.503
Epoch 3/20 - Train loss: 0.2117, acc: 0.915 | Val loss: 1.4210, acc: 0.490
Epoch 4/20 - Train loss: 0.1446, acc: 0.949 | Val loss: 1.5470, acc: 0.504
Epoch 5/20 - Train loss: 0.1212, acc: 0.957 | Val loss: 2.8695, acc: 0.494
Epoch 6/20 - Train loss: 0.1040, acc: 0.962 | Val loss: 1.6452, acc: 0.502
-> Early stopping déclenché.

Entraînement terminé.
Meilleur modèle enregistré dans : models/best_cnn3d_tuh.pth
```

Test

```
Confusion matrix :
[[701 296]
 [871 617]]

Classification report :
precision    recall    f1-score   support
          0       0.446      0.703      0.546      997
          1       0.676      0.415      0.514     1488

accuracy                           0.530     2485
macro avg       0.561      0.559      0.530     2485
weighted avg    0.584      0.530      0.527     2485
```

THANK YOU FOR YOUR ATTENTION

Presented by:

OUDAY MESSAADI

OUSSEMA CHERNI

Contact:

EMAIL ADDRESS

ouday.messaadi@etudiant-enit.utm.tn

oussema.cherni@etudiant-enit.utm.tn